



EVO App features


Version 1.2.77



DOKENSIP EVO App features

Login Screen	3
Registering a new system	4
Main screen	6
Sensor information	7
Core settings : General, Icon, Alarms, Geofence, Call Center	8
Core settings : Main screen view	13
Core settings : Scheduled actions	14
Management options	16
Anchoring	17
Sensor data, Historical data and sensor alarms	18
Sensor configuration	21
App setup	22
Invoices	27
Warranty	28
Installation pictures	32
Map	33
DOKIES	38
SIDERS	41
Weather, moon and tides	44
Subscription renewals	46
Password recovery	49
MAP Process	50
Testing data	51

Login Screen



Language to be used in the app.


User credentials to log in the app.

Password recovery process

Register and activate your system if this is the very first time in the app, and your system has not been activated before.

App version. Please, keep always updated.

Registering a new system



5:49

Register new Pack

Cancel

Verify activation card
Check user availability
Fill in user data
System activation

Sign up as a new user and activate your pack.

Read activation card


Code A

Code B

Next

You need access to the activation card provided with your pack. You can read the QR Code in the card, or insert both codes.

Keep updated with information regarding new DOKENSIP products.



6:08

Register new Pack

Cancel

Verify activation card
Check user availability
Fill in user data
System activation

Select username and password

User
Evo

Password
.....

Confirm password
.....

Information of new products ☒

[I accept privacy policy](#) ☒

Check availability

Choose your username and password. If it's available, it will be assigned to you.

EVO

Registering a new system

6:11

Register new Pack

Cancel

Verify activation card
Check user availability
Fill in user data
System activation

Contact Information

First Name
Dokensip EVO

e-mail
noreply@hiruteknova.com

Phone
606606606

Name of the vessel
My Core

Check availability

Fill in your email address. It will be used to send a notification when an alarms occurs.

Insert your phone number with international prefix. It's important that you have access to that phone, as you'll receive an SMS (once you tap on "Check availability") with a pin code to verify your phone.

Select the system "alias". Usually, vessel name

6:13

Register new Pack

Cancel

Verify activation card
Check user availability
Fill in user data
System activation

System activation

Correct data. Activate your system!

Activate system

Click here to activate your system. Once finished, some internal processes will happen for a couple of minutes, to activate everything. You can now login with your username and password.

Main screen

Core state.
Green if connected to
power, red if not (backup
battery mode)

Geofence

Anchoring

App configuration



Current active CORE. In case there is more than one,
selector mode on

Access to Dokie menu. Green if detected, red if not

SIDER menu. Green if detected, red if missing, grey if
no SIDERS linked to the CORE.

Weather, moon and tidal information.
Icon shows current weather at CORE's position

Sensor information, and general state.

- (Green) => Active and correct
- (Red) => Active and on alert
- (Grey) => No data ever received
- (Purple) => No data received in the last 60 minutes

Map, Geofence, positions and sharing

EVO

Sensor information

System state icon

- (Green) => Active and correct
- (Red) => Active and on alert
- (Grey) => No data ever received
- (Purple) => No data received in the last 60 minutes

Time of last data reception

Core setup

Anchoring state & options.

- (Green) => Active and OK,
- (Red) => Active and outside of security distance
- (Grey) => Not active.

Sensor listing



Core information

- Power state
- Number of satellites attached
- GSM level
- Hardware / firmware versions


Management configuration.

Only seen if under management. Managers will request control of system with “Yacht Manager” app. Once granted by owner, they’ll receive notifications,

Add new sensors to your system by reading the QR Code located in the battery holder.



Core settings - General



Change system name

Select the icon to be shown in the map

Personalize main screen appearance.

If allowed by your subscription, with Scheduled Actions you could chain an action with sensors when one of them change its state.


Disarm system. No data will be received until reactivation, so there won't be alarms or information regarding this system. When disarmed, button will be enabled to "Rearm" system again.

If allowed by your subscription, you can pause your yearly subscription for a maximum of 6 months, so expiration date will be extended while service is paused. While paused, no data will be received by the Core. Only one pause is allowed in every yearly subscription

Will restart Core in the next transmission. If there's no GSM / SAT coverage, it won't be executed

EVO


Core settings - Icon



Select the icon to be used in the map.

Core settings - Alarms


Language to be used for the alarms. (If your language is not here, let us know).



Activate / deactivate system alarms. If disabled, no alarms will be received. After 96 hours,(4days), they will be automatically activated again.

When active, and a Dokie is detected on board, alarms won't be triggered, and there won't be any notifications. Useful if the owner gets into the boat, so he doesn't have to acknowledge the alarms. Default is "active".

Core settings - Geofence




Geofence alarm state.

Type of alarm if boat leaves assigned geofence. "Push only", will just send a push notification, while "Complete alert" will trigger all MAP process.

Core settings – Call Center

Language in which you'll receive Call Center's call.



Call Center active or not. If your subscriptions allows Call Center, it can be enabled / disabled from here. (Check MAP process)


Extra contacts. You can define up to 3 extra contacts. Those contacts will receive calls from Call Center after you, if not attended. Please, don't fill your personal data, as it is included already as primary contact.

Core settings – Main screen view


Available views

If you hide one item, cell near it will be expanded to fill all the row.


Classic





Modern



4 elements




6 elements




Select sensor to view from the list of available items. You could chose Weather information, or hide one cell.

Core settings – Scheduled actions




Create new scheduled action

List of defined Scheduled actions. Slide from right to see menu.



You can see scheduled action definition, or remove it. It's not possible to edit scheduled actions. If you have to change it, remove and create again.

Core settings – Scheduled actions



Name of the scheduled action.

"Trigger" sensor. The sensor who will start actions when changing its state.

Action to execute when "Trigger" sensor goes on alarm. You can choose: "Do Nothing", "Turn on sensor" or "Turn off sensor".

"Triggered" sensor if on alert.

Action to execute when "Trigger" sensor recovers from alarm. You can choose: "Do Nothing", "Turn on sensor" or "Turn off sensor".

"Triggered" sensor when recovering from alert.

In scheduled actions, there's a "Trigger" sensor who will start actions on "Triggered" sensor. Every time a "Trigger" sensor enters or exits from alarm, will be executing defined actions on "Triggered" sensors.


Shore power, Battery, Bilge, Motion and Temperature sensors can act like "Trigger Sensor", while Relay and Siren will act like "Triggered sensors".

Management options

Who will receive alarms ?
Options available :

- Owner
- Manager
- Both

If “Yes”, both alarms and warning will be triggered to Manager, if allowed. If “No” Manager only will receive Alarms




Suspend temporally management. For example, if you go sailing for some days, you might not want the manager to know anything about to the boat while you're sailing.

Cancel management. After cancelling, Manager should request management again.

Allow the Manager see the position of the boat on the map. If disabled, Manager will only see state of the sensors.

Anchoring






Anchoring alarm will be watching the Core's position every second to check if the boat, once on the anchor, drags or moves beyond the defined radius.

Choose the swinging mooring's radius with the slide bar and it will be set automatically. When you set a new radius or you change the current one, the Core needs to confirm it, so it can take up to 3 minutes to be OK.

Sensor data

Depending on the type of sensor, you will see one of these screens



Tap on the graph to see historical data


Historical data



Historical data is shown in landscape mode. Once you leave this screen, app should restore portrait mode again.

Hours to see in the graph

Sensor alarms



Name of the DOKIEs detected when the alarm was triggered, if any.

Last month alarms will be shown. Date and time displayed is relative to Core's position.



Alarm list :

- Red : Sensor goes on alarm
- Green : Sensor recovers from alarm

Sensor configuration


Numerical sensor

You can set up maximum and minimum for Battery, Shore Power and Temperature sensors. Values outside these limits will trigger an alarm. Click on values to change them



Scroll the wheel to change values.

Not numerical sensor




Change the name of the sensor

If sensor is NOT active, you'll see it black in the list of sensors, and you won't receive any data for this sensor.

Remove sensor from your system.
Do not remove any sensor if you're not told to do it.

App setup – User -> General



Invoices, Warranties..

Previous notifications list

Temperature system


Size units

Change your password

Delete data stored in the phone. Requires login.


Add a new system to your account.

Logoff current session




EVO

App setup – User -> Profile




Profile picture. Take a new picture or choose one from your gallery

User information. Please fill in with all the information. It will be used later to create the invoices of future renewals.



EVO

App setup - Application




Date and time format to be used
in the app

App language

App version


App setup - Silence



You can select the days / hours for the app to be quiet. During these periods you won't receive any notification. In the example shown from Saturday 23:00 to Sunday 08:00, and from Sunday 23:00 to Monday 08:00, no alarm will be received.

Select the time zone of your location, not the Core's location Time zone.

App setup – User -> More...



Invoices list


Warranty requests

Pictures of the installation.

Pictures are mandatory to start a warranty process

Application manual, will be opened in system's navigator

App setup – User -> More...> Invoices




Economic data

Details of the service renewed

Tap to receive selected invoice in your inbox.

App setup – User -> More...> Warranty




Start a new warranty process.
You need your email filled in
your profile.

RMAs requested

Details of the RMA process

RMA = Return Merchandise
Authorization



EVO


App setup – User -> More...> Warranty



Start warranty request


All DOKENSIP EVO product have 2 years warranty, starting on first activation date.

Select your system, then you'll have to choose devices with problems.



EVO


App setup – User -> More...> Warranty



Select device not working properly. Only devices in warranty period could be selected. If there's another warranty opened, devices in it won't be listed.


If you have chosen more than one device, after completing the information on the first one, swipe left, and fill in the form for the remaining ones.

For every device you have chosen, you have to confirm the questions made. Also, you have to provide a description for the problem for this device.




App setup – User -> More...> Warranty

Confirmation screen



Tap to start warranty process

Assigned ID for the RMA




All devices will be checked on reception. If it's a faulty device, it will be replaced or repaired, and sent back to you at no cost. If it's a bad use of the product, not faulty, or you have not checked all the steps you have confirmed in the warranty screen, it will be returned at your cost.

EVO

App setup – User -> More...> Pictures

Pictures of the installation are mandatory before starting a warranty claim. Please, ask your installer to take the pictures while installing your system




Click to delete a picture.

List of devices associated to the current Core.


Click to assign a picture. When taking a picture try to show the surrounding area where the device is installed. You can assign more than one picture to every device.

Choose "My Pictures" to assign a previously taken picture, or "Camera" to take picture and assign.



EVO

Map




Boat's current position

Floating Menu:

- Filter positions
- Geofence operations
- Share location / Route


Map - Filter



Select the interval to be shown.



Map - Geofence

Current geofence
Enter into edit mode



“Save” and “Back” to
set the new geofence

When editing or creating
geofence, you can drag vertex
to adjust them, double tap
in vertex to delete, or tap
between vertex to create a
new one.





If Geofence is set, every time a position is recorded, its checked against the Geofence. If the boat leaves the geofence, the MAP process is triggered. If the boat returns to the assigned Geofence, only a Push will be sent.


EVO

Share position / route


It's possible to generate a link to share with friends and family, so they can follow you in your trip. You should set the duration of the link (after that it won't be available), and tap on "Create Link"



While sharing, you will see the time left, and you can stop sharing.



Share position / route




The people with whom you have shared your location will see your boat's position, and if set, the route you're sailing. It's an external link, that can be opened with any browser.

EVO

DOKIES

Add a new DOKIE.
You can read the
printed QR Code,
or scan BLE
devices nearby.



Temporarily disable DOKIE. If disabled, alarms will be always be triggered, unless you have another DOKIE.

Removes the DOKIE from the system.


Setup DOKIE

Check DOKIE's battery and state

DOKIEs are custom beacons, with BLE technology that identifies the user in the boat. There's one DOKIE in you DOKENSIP EVO Pack, but you can have as much as you like (family, mechanic, clean...)

EVO

DOKIE's setup




Change your DOKIE's name

Select sensors muted by this DOKIE.

Current Dokie **WILL NOT** mute Engine Battery and Main Power alarms.

You can select sensors affected by every DOKIE, so for example, Mechanic's DOKIE won't mute Captain's room motion sensor.


Check my DOKIEs



← Your devices

← Other discovered devices NOT assigned to your system

SIDERS



Temporarily disable SIDER. If disabled, alarms won't be triggered.

Removes the SIDER from the system.


Setup SIDER

Add a new SIDER. You can read the printed QR Code, or scan BLE devices nearby.

SIDERS are custom BLE devices to check that some good is on board. As soon as the SIDER is not detected on board, an alarm will be triggered. Use it, for example, with your dingie, outboard engine, or so.


EVO

SIDER's setup




Change your SIDER's name

Add DOKIE / SIDER




You can read the QR Code printed in the DOKIE / SIDER or if removed or not readable, scan for BLE devices nearby




After Scanning, you will see a list of discovered DOKIES and SIDER. Only devices in blue are available to be added to your system.

Weather, Moon and Tides




Core's current location information of position, sunrise / sunset, and weather.

5 Days forecast, rain, wind, temperature, humidity and pressure.



EVO


Weather, Moon and Tides




Current Moon phase.

Tide graph and hours

Please, use this information carefully. It's shown as a reference, and can't be used for navigation purposes.




Subscription renewals




When service is near to expire, the “Renew subscription” button will appear. If subscription has expired, you will not be able to check any information. You will be notified by mail when service is about to expire.

Choose one of the available subscriptions. These can be different in your country. You can check their features, and tapping on the blue column, you will see a brief description. (Prices shown don't have to be real)



EVO

Subscription renewals



9:52

← Renew subscription

We need to collect certain information for payment.

First Name
EVO

VAT Number


Phone
+34616363636

E-Mail address
noreply@hiruteknova.com

Is it company? ☐

Next Cancel

Complete with your personal information. If you already filled in before it will be updated automatically.



3:23

← Renew subscription

We are almost done...

Address
Some Address

Postal code
00000

Town
Some Town

Province
Some Province

País
Spain

Next Cancel




EVO

Subscription renewals

Credit Card information. It's a Secure Payment through Stripe, implementing 3D Secure.


Confirm the payment, we're almost done.

Congratulations, your subscription is renewed..



EVO

Password recovery



5:51

← Recover password

Password recovery

Enter the username and email defined in your current user account. An email will be sent with a new password to access the application. Later you can modify it from your user profile..

User

Current email


Request password

Insert your username

Insert your email address. It should be the one registered with the user. You'll receive an email in that address

To recover the password, the user code must be known, as well as the associated email address. The password will be reestablished with a random temporary one, which can be modified from the application in the user profile, once authenticated.

MULTICHANNEL ALERT PROCESS



With MAP process, you will be notified when something happens on board, sure !!

Download app from your store



DOKENSIP EVO (*)

Username : evodk

Password : demo

() Old app is called "Dokensip", be sure to download "DOKENSIP EVO"*




Keep calm, if something happens, we'll notify

(wireless)

FCS»»

MAP



DOKENSIP EVO

We evolve with you !